

TULIKUKKO S - pellet burner

The use and safety instructions



tulikukko



1

Adjust the burner to fit perfectly into hearth or firebox of your fireplace or stove, you can adjust both length and width. Open the damper and place the burner on the grate in your fireplace or stove or in the bottom of your open fireplace.



2

Fill the burner with pellets almost up to the level of the edges.



3

Don't push pellets into the air triangle, the burner gets compensation air through the air triangle.



4

Light a solid fire starter piece over the pellets, then push it with a tool to the back of the burner.



5

Pellets light up easily in the back of the burner.



6


Once the fire has spread across the burner, use the air intake control of your fireplace to adjust the flames so that they burn bright yellow and that the pellets burn evenly. When there are only embers left, adjust the air intake to as small as possible to avoid overheating the burner.



7

Pellets burn cleanly in a Tulikukko and there will be very little ashes created. You must clean the burner every time before using it again.

If you follow these instructions, you can enjoy your burner for a long time!



SAFETY INSTRUCTIONS:



- ask the manufacturer of your fireplace or stove to check that it is suitable for burning pellets
- make sure the damper is open
- make sure that the smoke detector in the room is in working order
- make sure that the air-conditioning is correctly set
- follow the instructions of air-conditioning
- do not use fire starter fluids (only solid fire starters)
- do not touch the burner after lighting and do not remove it from the fireplace or stove
- burning produces toxic gases; do not close the damper until the embers have burned out
- the room should also have a carbon monoxide detector
- check the condition of the burner before lighting
- clean up the cold ashes from the burner before you refill it
- do not ever refill more pellets on hot embers
- let the pellets burn out without touching them
- do not leave the burner unchecked when it has a fire on

Note ! Do not open the door of your fireplace or stove when there is a flaming fire on the burner!

